

## Firefly Motion-Activated LED Light Modules

The Firefly provides energy-saving lighting only when you need it. Mount a Firefly inside a cabinet or closet, in a hallway or stairwell—anyplace that requires a small area of temporary illumination.



### Features

- **Self-Contained**—module uses 3 AAA batteries (included), 6 white LEDs, infrared motion sensor and control circuit
- **Easy Installation**—via self-adhesive mounting plate or simple screws—no wiring
- **Fully Automatic**—turns on when motion is detected; off after 8 seconds without motion detection; stays off when ambient light is bright enough
- **Miniature Size** —fits almost anywhere!



### Ordering Information

Series	Time Delay	Motion Detection Range	Average Battery Life	Power Supply	Dimensions
PAC0547	8 seconds	10 feet	3 years*	3 AAA Alkaline Batteries	2.5" x 2" x 1.75"

\*Battery life depends on use